



PLATELET -POOR PLASMA PREPARATION INSTRUCTIONS

1. Centrifuge the 2.7 mL Light Blue Sodium Citrate Tube.
2. Transfer the plasma to a labeled plastic transfer tube.
3. Re-spin the plasma.
4. Remove 2/3 of the re-spun plasma to a second labeled plastic transfer tube. Label this tube as "Platelet-Poor Plasma and indicate the date and time of collection.
5. Freeze the platelet-poor plasma for transport to the laboratory.